



# TROUBLESHOOTING GUIDE



---

Version 4  
PL-TRA-TSG-EN



---

[www.proloncontrols.com](http://www.proloncontrols.com)  
1-877-977-6566  
[info@proloncontrols.com](mailto:info@proloncontrols.com)  
17510 Rue Charles, Suite 100, Mirabel, QC, J7J 1X9

---



## Table of Contents

System Start-Up.....	3
VC2000 VAV Controller.....	5
Zone Troubleshooting.....	6
RTU/AHU Controller Troubleshooting.....	8
Network Troubleshooting.....	8


© Copyright 2026 Prolon. All rights reserved.

No part of this document may be photocopied or reproduced by any means, or translated to another language without prior written consent of Prolon. All specifications are nominal and may change as design improvements are introduced. Prolon shall not be liable for damages resulting from misapplication or misuse of its products. All trademarks are the property of their respective owners.



# System Start-Up

**Step 1:** Checking each controller's Heartbeat blue LED light: "HBEAT".



HBEAT light on a M2000




HBEAT light on a NC2000



HBEAT light on a VC2000

**Step 2:** Checking each controller's communication LED lights: "NETSND" & "NETREC".

Power up the zone controllers first. Once done, power up the unit controller. **Eight seconds after the unit controller is powered up, communication will be established with its zones.**




NETSND / NETREC light on a M2000




NETSND / NETREC light on a VC2000



**Step 3:** Checking the LED output lights.  
H-O-A Override switches.



**Led output lights on a M2000 (RTU)**



**M2000 Switches**

**Step 4:** Manual procedure to invert damper opening direction (CW/CCW)



**[ 4A ]** Confirm actual damper opening direction by resetting power on the controller.



**[ 4B ]** To change direction, first unplug the power terminal block.



**[ 4C ]** Using a small screwdriver, press and hold the service button. **While holding, reapply power.**



**[ 4D ]** Immediately observe the yellow "STATUS" light.  
**Clockwise (CW):** - - - (blinks 3 times over 3 seconds)  
**Counter-clockwise (CCW):** (solid over 3 seconds)




# VC2000 VAV Controller

## Virtual Addressing

Network addressing of the VC2000 is now done virtually, without switches. It can either be configured with the help of the Focus software or with a display equipped digital wall sensor (T1000).



**When "Status" is on, no valid address is present in controller**





## Zone Troubleshooting

SYMPTOMS	WHAT TO DO
<p><b>[ A ]</b> The zones do not communicate</p>	<p><b>[ A1 ]</b> Make sure all controllers are supplied with 24VAC and that each have their HEARTBEAT flashing (including unit controller).</p> <p><b>[ A2 ]</b> Verify that the communication bus polarity is the same for all zone controllers and unit controller as well.</p> <p><b>[ A3 ]</b> Verify the 24VAC supply polarity is the same for all zone controllers and that the transformer's neutral is grounded.</p> <p><b>[ A4 ]</b> Make sure the terminating resistors have been correctly activated on the appropriate controllers.</p>
<p><b>[ B ]</b> The communication "NETREC" green LED light is continuously lit on one or many zone controllers</p>	<p><b>[ B1 ]</b> The communication bus and/or 24VAC supply polarities are reversed on one of the controllers. Verify and rephase.</p> <p><b>[ B2 ]</b> If needed, check network status with the voltage measurement technique. (See Section #3 "Network Troubleshooting")</p>
<p><b>[ C ]</b> The zone controller damper does not seem to respond to the thermostat inputs</p>	<p><b>[ C1 ]</b> Supply: Verify there is 24VAC and HEARTBEAT ("HBEAT").</p> <p><b>[ C2 ]</b> Reset: Push the reset button to validate the dampers rotation. (See Section #4 "Zone damper rotation change")</p> <p><b>[ C3 ]</b> Temperature limits: The ambient temperature must be within the setpoint limits.</p> <p><b>[ C4 ]</b> Supply air temperature: Must match the corresponding demand mode.</p>
<p><b>[ D ]</b> The damper opens in the opposite direction</p>	<p><b>[ D1 ]</b> Reset: Reset power to validate the dampers rotation. (See Section #4 "Zone damper rotation change")</p>



SYMPTOMS	WHAT TO DO
<p><b>[ E ]</b> The T500/T1000 digital wall sensor does not work (display blank or no temperature reading)</p>	<p><b>[ E1 ]</b> Verify that the zone controller have 24VAC supply and HEATBEAT ("HBEAT").</p> <p><b>[ E2 ]</b> Make sure the 24VAC jumper on the C1050 controller is activated (left of the RJ45 port, upper right corner).</p> <p><b>[ E3 ]</b> Verify connections and wiring polarity between the C1050 and T500/T1000 (using LVT 4/18 with ProLon PL-T1000-ADAPT, terminals 1, 2, 3, 4 on both ends).</p> <p><b>[ E4 ]</b> Verify connection (using straight CAT-5 // RJ45 terminated cable --- NO CROSSOVER! ---)</p>
<p><b>[ F ]</b> The T500/T1000 sensor displays: "Scan mode". The "INTREC" LED light is lit on the zone controller.</p>	<p><b>[ F1 ]</b> Communication problem / polarity reversal: Verify cable &amp; connections</p> <p><b>[ F2 ]</b> Addressing: Verify that the controller has an address between 1 and 127 (C1050/VC2000)</p>
<p><b>[ G ]</b> One of the digital outputs does not work</p>	<p><b>[ G1 ]</b> Verify the output state (Red LED). Note that LED remains on even with output in overload condition.</p> <p><b>[ G2 ]</b> Output mode selection: Active 24VAC ("SOURCE") or dry contact ("SINK"). Check for external jumper (VC2000) or position of switch (C1050/VC2000)</p> <p><b>[ G3 ]</b> Short-Circuit or overload: Unplug output wires and let thermal fuse cool. Fix the problem and replug wires.</p> <p><b>[ G1 ]</b> Outdoor air or morning warm-up interlock sequence (pnly DO #3 &amp; DO #4 aggacted). See unit controller serrings using ProLon Focus Software.</p>
<p><b>[ H ]</b> Analog output does not work</p>	<p><b>[ H1 ]</b> Verify the output state (Orange LED). Note that LED turns off when outputs is in overload condition.</p> <p><b>[ H2 ]</b> Short-Circuit: Verify +/- polarity.</p> <p><b>[ H3 ]</b> Outdoor air or morning warm-up interlock sequence: (See unit controller settings with ProLon Focus software.)</p>



## RTU/AHU Controller Troubleshooting

SYMPTOMS	WHAT TO DO
[ I ] The communication LED Lights do not flash ("NETREC" & "NETSND")	[ I1 ] See "The zones do not communicate". (Section #1 Zone troubleshooting)
[ J ] Heating or cooling do not activate on the air handler unit	[ J1 ] Verify the proof of fan.
	[ J2 ] Keep in mind the default 5 minutes off-delay upon initial system start-up.
	[ J3 ] Ensure that all zones are communicating and have the same demand.
[ K ] Economizer sequence does not work Modulating preheating sequence does not work	[ K1 ] Outdoor air & supply air sensors: Verify proper connection and positive reading of temperature. (See Unit Controller using ProLon Focus software)

## Network Troubleshooting

### Galardo Technique (Voltage measurement procedure)

- Step 1:** Unplug the unit controller (M2000) from the zone network cable.
- Step 2:** De-activate the terminating resistor jumper from the last zone controller.
- Step 3:** At any point on the network, perform a DC voltage measurement between each of the NET A & NET B (#15 and #16) communication connectors and neutral (#1)
- Step 4:** Voltage between "A" and neutral should read about 2.7Vdc.
- Step 5:** Voltage between "B" and neutral should read about 2.7Vdc.
- Step 6:** Should the readings be different, unplug all zones from network and re-plug one at a time while taking new readings until the faulty zone is found.

