

Wall Sensors and Thermostats		Wall Sensor				Thermostat
		PL-RS (F or A)	PL-T200	PL-T500	PL-T1000	PL-T1100
Unit Controllers	PL-M2000-RTU	#18/3	/	/	/	#24/2
	PL-M2000-HP					
	PL-C1000-RTU	/	/	/		
	PL-C1000-HP					
	PL-M2000-RTUS	#18/3	#24/2 + #18/2			/
	PL-C1000-RTUS	/	Cat5e or #18/4 + PL-T1000-ADAPT			
	PL-C1000HPS					
Zone Controllers	PL-VC2000	/	Cat5e or #18/4			/
	PL-VC2000-PI					
	PL-C1000-VAV	#18/3	Cat5e or #18/4 + PL-T1000-ADAPT			/