

Wall Sensors and Thermostats		Wall Sensor				Thermostat
		PL-RS (F or C)	PL-T200	PL-T500	PL-T1000	PL-T1100
Unit Controllers	PL-M2000-RTU	#18/3				#24/2
	PL-M2000-HP					
	PL-C1000-RTU					
	PL-C1000-HP					
	PL-M2000-RTUS	#18/3	#24/2 + #18/2			
	PL-C1000-RTUS		Cat5e or #18/4 + PL-T1000-ADAPT			
	PL-C1000HPS					
	PL-M2000-MUA	Thermistor ONLY #18/2				#24/2
Zone Controllers	PL-VC2000		Cat5e or #22/4			
	PL-VC2000-PI					
	PL-C1000-VAV	#18/3	Cat5e or #22/4 + PL-T1000-ADAPT			